

STAR ASIA HCM12A

2D Barcode Scanner User's Manual

Technical Support:



*This manual is subject to change without prior notice *

Introduction

This user's manual is designed for 2D barcode scanner. For detailed usage manual information, please download the complete user manual from our website or obtain from our distributor.

Programming the Scanner

☐ Restore Factory Setting



Restore Factory Setting

Scanning the following barcode can restore the scanner to the factory defaults.

“*”denotes default setting

☐ Data interface



*USB-KBW



RS232



USB-VCP

☐ Scan Mode



*Ordinary sensitivity



Low sensitivity



High sensitivity

☐ Terminal



Disable



*Enter(0x0D)



TAB



0x0D+0x0A

 Baud Rate



*9600



38400



1200



57600



4800



115200



19200

Global Settings



Enable all codes



Disable all codes



Enable 1D codes



Disable 1D codes



Enable 2D codes



Disable 2D codes



*Allow to read code 39



Not allow to read code 39



*Allow to read code 128



Not allow to read code 128