

Switching Scan Mode

切換掃描模式

Scan Mode I (Default) ◆ 掃描模式 I (預設)

Scan Mode II ◆ 掃描模式 II

Scan Mode III ◆ 掃描模式 III

Toggle Scan Mode ※ 切換掃描模式

The LED at top indicates the current scan mode.
Press button can toggle scan mode. Users can select 3 kinds of scan mode, stated at next page.
If "Switching Scan Mode" is "Manual Switch" (Default), user can press top button to change from "Yellow" scan mode to "Blue" scan mode.
If "Switching Scan Mode" is "Auto Switch", under "Yellow" scan mode, after successful decoding or 30 seconds timeout, the scanner will switch to "Blue" scan mode automatically.

General Mode	Scan printed barcode, Barcode on mobile phone screen, Mini Barcode
1D Fast Mode	Fast scan 1D printed barcode, 1D Barcode on mobile phone screen
Turn Off Scan	Stop scanning

掃描器頂部按鍵可以快速切換下列掃描模式，藍/黃 LED 燈代表當前模式。
掃描器可以設定3種掃描模式，見右頁的"掃描模式 I/II/III"
設定為"手動模式"時，在黃燈模式下，按鍵一次便切換回藍燈模式。
設定為"自動模式"時，在黃燈模式下，掃描成功或 30秒逾時後，便自動返回藍燈模式。

通用模式	掃描各種印刷條碼，手機螢幕條碼和迷你條碼。
1D快速掃描	快速掃描大量紙質或手機螢幕一維條碼。
關閉掃描	掃描器停止運作。

LED Indicator
LED 指示燈




LED Indicator
LED 指示燈




LED Indicator
LED 指示燈




Manual Switch (Default)
手動切換(預設)



General Mode 通用模式




Turn OFF Scan 關閉掃描




Turn OFF Scan 關閉掃描



1D Fast Mode 1D快速掃描模式



General Mode 通用模式



1D Fast Mode 1D快速掃描模式

Auto Switch
自動切換

